



**AXIAL PISTON VARIABLE DISPLACEMENT PUMP
 SPARE PARTS**

Position	Quantity	Part Description	Code number						
			Size 033	Size 052	Size 070	Size 089	Size 119	Size 166	Size 334
1	1	servovalve assembly	M100514	M100514	M100514	M100514	M100115	M100582	3360009482
2	1	charge pump ass'y, CW	M100946	M100948	M100950	M100950	M100662	M100664	33600163631
		charge pump ass'y, CCW	M100945	M100947	M100949	M100949	M100663	M100665	33600163631
3	2	servo cylinder	M201878	M201878	M100504	M100504	M201373	M201373	3360009172
4	2	servo piston	M201879	M201879	M201349	M201349	M201374	M201374	3360009182
5	1	front cover	M100974	3360008831	M100505	M100509	M000168	M000157	3360008761
6	1	pump housing	M000301	3360008811	M000146	M000149	M000163	M000156	3360008531
7	1	end cap	M100977	3360008771	M000147	M000150	M000153	M000158	3360008741
8	1	swash plate	M201880	3360008731	M100507	M100511	M100651	M000159	3360009212
9	2	check valve	M302327	M302327	M302327	M302327	M302526	M302528	M302528
10	1	cylinder barrel	M101031	3360008521	M100960	M100961	M101039	M101040	M101042
11	9	piston assembly	M302502	3360015643	M302504	M302505	M302506	M302507	M302509
12	1	bearing plate	M201958	3360009252	M201866	M201867	M201960	M201961	M101044
13	1	retainer guide	M201962	3360004042	M201868	M201869	M201964	M201965	3360009402
14	1	slipper retainer	M302518	3360015613	M302315	M302316	M302520	M302521	3360016293
15	1	spring retainer	M406634	3360028464	M406358	M406359	M406636	M406637	M406639
16	1	spring seat	M406640	3360029114	M406360	M406361	M406642	M406643	M406645
17	1	spring guide	M406614	3360029124	M406356	M406357	M406616	M406617	M406619
18	1	bearing plate pilot	M406608	3360027404	M406353	M406354	M406610	M406611	M406613
19	1	pin	M406646	M406646	M406355	M406355	M406355	M406355	M406647
20	1	cylinder barrel spring	M406660	3360029364	M406371	M406372	M406662	M406663	M406665
21	6	retainer spring	M406666	M049479	M406373	M406374	M406668	M406669	M406671
22	1	retaining ring	M888101	M888102	M888103	M888104	M406624	M406625	M406627
23	1	thrust plate	M302357	3360015623	M302317	M302318	M302524	M302525	33600016313
24	1	valve plate CW	M201942	3360009232	M201862	M201864	M201947	336001592	3360009412
	1	valve plate CCW	M201941	3360009222	M201863	M201865	M201968	3360010602	M201957
25	2	trunnion	M302351	3360016453	M301615	M301616	M201375	M201376	3360009192
26	1	seal retainer	M301617	M301617	M301617	M301618	M301618	M301618	33600016323
27	1	rotating seal	M301619	M301619	M301619	M301620	M301620	M301620	33600029134
28	1	stationary seal	M301621A	M301621	M301621	M301622	M301622	M301622	3360016353
29	1	drive shaft	M201926	3360009272	M201350	M201352	M201484	M201487	3360009442

**AXIAL PISTON VARIABLE DISPLACEMENT PUMP
 SPARE PARTS**

Position	Quantity	Part Description	Code number						
			Size 033	Size 052	Size 070	Size 089	Size 119	Size 166	Size 334
30	2	servo link	M406540	M406540	3360001583	3360001563	M405183	M405199	3360029144
31	2	sleeve retainer	M406477	M406477	M404720	M404720	M405179	M405179	3360016393
32	2	spring guide	M406544	M406544	M404721	M404721	M405180	M405180	3360016403
33	1	shim	M406478	3360018494	M404723	M404724	M405191	M405210	3360029164
34	2	washer	M406581	M406581	M404725	M404725	M405190	M405190	3360029154
35	1	orifice	M404727	M404727	M404727	M404727	M404727	M404727	M404727
36	1	spacer	M404728	M404728	M404728	M404728	M404728	M404728	M404728
37	1	control handle	M301623	M301623	M301623	M301623	M301623	M301623	M301623
38	3	loop	M404729	M404729	M404729	M402739A	M402739	M402739A	3360029184
39	2	cap	3360002793	3360002793	3360002793	3360002793	3360002793	3360016373	3360016373
40									
41	1	control valve gasket	M301624	M301624	M301624	M301624	M301624	M301624	M301624
42	1	charge pump gasket	M301625	M301625	M301625	M301625	3360019223	3360019223	M301831
43	2	shim pack	M406543	3360029674	M404730	M301626	M404763	M405197	3360029214
44	1	end cap gasket	M201921	M003145	M201354	M201356	M709287	M005124	M005678
45	1	front cover gasket	M201923	3360009492	M201355	M201357	M201485	M201488	3360016413
46									
47	6	seal spring	M404731	M404731	M404731	M404731	M404731	M404731	M404731
48	2	servo spring	M406462	M406462	3360001794	3360001794	M405198	M405198	3360029624
49	1	nut	M404733	M404733	M404733	M404733	M404733	M404733	M404733
50	3	plastic plug	M402624	M402624	M402624	M402624	M402624	3360031274	M404735
51	1	plug	M404735	M404735	M404735	M404735	M404735	M404735	M404735
52	4	expander 05	3360001744	3360001744	3360001744	3360001744	3360001744	3360001744	3360001744
53	1	expander 09	3360001754	3360001754	3360001754	3360001754	3360001754	3360001754	3360001754
54	9	hex head screw	M404737	M404737	M404737	M404737	M404735	M405207	M404737
55	4	hex head screw	M406542	M406542	M404738	M404738	M405185	M405204	3360029324
56									
57	8	hex head screw	M404741	M404741	M404741	M404745	M405188	M405188	3360029314
58	3	end cap screw	M404742	M404742	M404742	M404747	M405186	M405203	3360029294
59	5	end cap screw	M404743	M404743	M404743	M404748	M405187	M405205	3360029284
60	2	screw	M404750	M404750	M404750	M404750	M405182	M405182	M405182

**AXIAL PISTON VARIABLE DISPLACEMENT PUMP
SPARE PARTS**

Position	Quantity	Part Description	Code number						
			Size 033	Size 052	Size 070	Size 089	Size 119	Size 166	Size 334
61	6	hex head screw	M406541	M406541	M404740	M404744	M405189	M405207	3360029304
62	1	pin	M404751	M404751	M404751	M404751	M404751	M404751	M404751
63	4	pin	M406547	M406547	M404752	M404752	M405184	M405184	3360027364
64	1	drive screw	M404753	M404753	M404753	M404753	M404753	M404753	M404753
65	1	pin	M406546	M406546	M404754	M404754	M404754	M404754	M404754
66	4	pin	M404757	M404757	M404757	M404757	M404757	3360029204	3360029204
67	1	retaining ring	M404758	M404758	M404758	M404759	M404759	M404959	336001735
68	2	retaining ring	M404959	M404959	M404959	M404959	M404959	M404959	M404959
69	8	retaining ring	M294013	M294013	M888107	M888107	M888107	M888107	M013615
70	2	O-ring	M406467	M000935	M404761	M404762	M404753	M888304	M001008
71	1	O-ring	M404763	M404763	M404763	M405672	M405672	M000992	M000992
72	1	O-ring	M404765	M404765	M404765	M404765	M404765	M404765	M404765
73	2	O-ring	M008821	M008821	M008821	M008979	M008979	M008979	M012187
74	2	O-ring	M406468	M406468	M406471	M406471	M000901	M000901	M000919
75	2	O-ring	M406466	M406466	M406470	M406470	M000893	M000893	M015545
76	4	O-ring	M406480	M406480	M406480	M406480	M406480	M406480	M406480
77	1	bearing	M999901	M999901	M999902	M999903	M999905	M999906	M999908
78	1	bearing	M999911	M999911	M999913	M999914	M999915	M999916	M999918
79	2	bearing	M999921	M999922	M999923	M999924	M999925	M999926	M999928
80	20	washer	M888005	M888005	M888005	M888006	M888008	M888011	M888012
81	13	washer	M888001	M888001	M888001	M888001	M888009	M888006	M888012
82	1	washer	M888002	M888002	M888002	M888002	M888002	M888002	M888002
83	4	drive screw	M888201	M888201	M888201	M888201			
84	6	washer	M888004	M888004	M888005	M888006	M888010	M888006	M888006
85	1	link swashplate	M404794	M404794	M404715	M404715	M405178	M405178	3360029194
86	4	socket head screw	M404749	M404749	M404749	M404749	M404749	M404749	M007419
87	2	O-ring	M888301	M888301	M888301	M888301	M888301	M001172	M888301
88									
89	4	hex head screw	M404741	M404741	M404741	M404745	M405188	M888011	3360029314

**HYDROSTATIC TRANSMISSION
SPECIAL SPARE PARTS**

PUMP			Code number						
Position	Quantity	Part Description	Size 033	Size 052	Size 070	Size 089	Size 119	Size 166	Size 334
1	1	Servo valve assembly			3360012991	3360012991			
2	1	charge pump ass'y, CW			3360014182	3360014182			
		charge pump ass'y CCW			3360013722	3360013722			
12	1	bearing plate			3360015882	3360015372			
24	1	valve plate CW			3360015872	3360015432			
		valve plate CCW			3360015862	3360015402			
37	1	arrest device			3360014572	3360014572			
48	1	servospring			3360059444	3360059444			

MOTOR			Code number						
Position	Quantity	Part Description	Size 033	Size 052	Size 070	Size 089	Size 119	Size 166	Size 334
1	1	manifold ass'y 350 bar			3360013712/1	3360013712/1			